

ASSEMBLY INSTRUCTIONS

Install Sub 10 Master & Client Installation in Furniture

FRONTFIRE & DOWNFIRE

- Net Volume: 30 L to max. 60 L
- Closed and Airtight Enclosure
- Sturdy, furniture-integrated enclosure: Minimum 16 mm panel material (MDF, plywood, chipboard)
- Acoustic fleece / insulation mat: Minimum 5 cm clearance from electronics
- Cable entry must be airtight
- Cutout size: Ø 258 mm / 10.2"
- For Downfire: Minimum 5 cm clearance from the floor
- Use suitable adhesive feet (rubber, felt) for decoupling



BAUANLEITUNG

Install Sub 10 Master & Client Einbau in Möbel

FRONTFIRE & DOWNFIRE

- Nettovolumen: 30 l bis max. 60 l
- Geschlossener und luftdichter Korpus
- Stabiler, im Möbel integrierter Korpus: mind. 16 mm Plattenmaterial (MDF, Multiplex, Spanplatte)
- Akustikvlies / Dämmmatte: mind. 5 cm Abstand zur Elektronik
- Kabeleinführung muss luftdicht ausgeführt werden
- Ausschnittgröße: Ø 258 mm / 10,2"
- Bei Downfire: mind. 5 cm Abstand zum Boden
- Zur Entkopplung geeignete Klebefüße verwenden (Gummi, Filz)

